

## P8509 CHOCOLATE PUMP



## SPECIFICATIONS, ADJUSTMENT & CLEANING

#### CARE AND CLEANING GUIDE



 Remove pump from food container and pump out and dispose food product remaining in pump.



2. Wash outside of pump and immerse in wash water while pumping to clear any remaining food product.



Remove bottom cap by twisting cap counter clockwise.



4. Use supplied brush to clean pump tube.



 Wash and sanitize pump and components. Make sure to pump detergent and sanitizer through pump.



Reassemble pump cap to pump and allow to air dry.

### **PUMP ADJUSTMENT**

The P8509 pump is adjustable up to 1/2 oz. portions





(Photo I) Unscrew set screw and remove lever. (Photo 2) Turn stem counter clockwise for a larger portion and clockwise for a smaller portion. Replace lever and set screw. Test the pump with the condiment to be dispensed and make additional adjustments if necessary.

#### **CUSTOMIZING THE KNOB**





The knob on the P8509 Chocolate Pump can be customized with any manner of wording or colored inserts. Simply unscrew the knob and either label the blank paper insert or replace with an insert of your choosing.




# P8509 CHOCOLATE PUMP



## SPECIFICATIONS, ADJUSTMENT & CLEANING

#### **SPECIFICATIONS**

The P8509 Chocolate Pump is designed to pump a variety of syrups and sauces. All components in contact with food are stainless steel. The cover, knob and sleeve above the cover are chrome-plated. The pump is designed to fit into most standard topping and condiment rails with 3-1/2 quart jars with rectangular tops.





555 Koopman Lane - Elkhorn, Wisconsin 53121 USA

Customer Care: 800.248.9826 T: 262.723.6133 F: 262.723.4204

Website: www.sanjamar.com Parts: www.edispensers.com