

# winco



**Contents:**

- (1) Dispenser
- (1) Cover ring
- (4) #10 Screws
- (2) Springs


## CDIC-4 IN-COUNTER CUP DISPENSER

The cup dispenser is completely assembled but it will require a simple adjustment once the dispenser has been installed. A full sleeve of cups is recommended for dispenser installation.


To dispense cups in horizontal mounting position use the spring already installed in the cup dispenser.

To dispense cups in vertical or angled mounting position the heavier compression spring will be required. Remove the dispenser's end cap and replace the spring.


### Installation Instructions




- 1** Cut a 5-1/4" diameter hole into the desired mounting surface. Turn the cover ring counterclockwise to separate from the dispenser.



- 2** Insert the dispenser into the mounting hole. **Note:** For horizontal or angled application, align the UP marking to the top. For vertical mounting, align the UP marking to the bottom.



- 3** Drill four 9/64" pilot holes in the screw holes. Fasten the dispenser with the four #10 screws provided. Insert full sleeve of cups. Slide 3 clips inward to adjust for cup size.



- 4** Replace cover ring by turning clockwise.